


## Fastener set RD-2 (bottom adjustment) - mounting instructions



- 1. Lighting fixture
- 2.1 Bottom hook
- **2.2** O-ring
- 2.3 Wire sliding block
- 2.4 Nut
- 2.5 Wire with clip
- 2.6 Ceiling bracket
- 3. Screw\*
- 4. Wall anchor\*

RD-2 set silver (ref. 42653NI), black (ref. 42653L9005), white (ref. 42653L9010), silver satin (ref. 42653GSS)

**NOTE!** All LED tapes must be connected to a 12 V or 24 V power supply.


**IMPORTANT:** Not all possible mounting procedures are presented here. More mounting procedures and related accessories can be found at www.KlusDesign.eu. Drawings of extrusions and accessories in these instructions are simplified and only approximate the actual shapes.

www.KlusDesign.eu 1

<sup>\*</sup>Screws and wall anchors are not included in the RD-2 set. Commonly available screws ø 5 mm for a given type of surface should be used (wall, drywall, wood, sheet metal, etc.).




## Fastener set RD-2 (bottom adjustment) - mounting instructions






## Fastener set RD-2 (bottom adjustment) - mounting instructions



Fix the hooks (2.1) in the small channels of the profile, place o-rings (2.2) and wire sliding blocks (2.3) on them.

2.3

Screw the wire blocks (2.3) onto the hooks.



Suspend the lighting fixture and adjust the length of the wires with the blocks (2.3).

The hinges in the fasteners allow the fixture to be tilted up to 90°.

www.KlusDesign.eu